



USB3.0 C/A to HDMI 4K30Hz x2 +HDMI 1080P60Hz x2 Display Adapter (Support MST)+USB3.0 Type-C(5G)

PRODUCT INSTRUCTION

Model:3244TU3

CENMATE

【Quality Assurance】Cenmate provides lifetime technical support.If you have any questions about the product, please don't hesitate to contact us, reply and solve your problem within 24 hours.

Technical Support Contact: cenmate23@outlook.com

Safety Guidelines

Please read the following safety instructions carefully before using this product for proper use and keep this manual for future reference.

- 1.Do not attempt to open the product to avoid electric shock.
- 2.Repair or maintenance should only be performed by qualified personnel.
- 3. Always place the product on a stable, flat surface to prevent it from falling off.
- 4.Do not expose the product to water, moisture or high humidity environment to avoid the risk of damage.
- 5.To avoid damage caused by direct sunlight or high temperature, do not expose the product to such environment.
- 6.Do not place the product near heat sources such as radiators, heat registers, stoves or other heat generating devices.
- 7.Do not place any object on the product to avoid damage.
- 8.Use only attachments and accessories specified by the manufacturer.
- 9. If not used for a long time, unplug the power supply to avoid damage.

Product Introduction

- 1.USB3.0 HDMI dual display adapter that connects USB-A or USB-C to four HDMI displays.
- It is designed to support replication/scaling/rotation/conversion/extend modes and supports maximum 4K@30Hz resolution.

System requirements

In order to install and operate the product correctly, please ensure that your system meets the following requirements: Windows 7/8/8.1/10 and above or Mac OS 10.x and above. CPU Processor: Core i5 and above. RAM: 4GB and above. Monitor: Supports 4K resolution.

Set Display Mode

The situation of Windows

The link address of the chipset manufacturer is shown below:

https://www.mct.com.tw/download.php?lang=en&tb=1&cid=32&ot=all

1.Please go to MCT official website,

click the upper right corner to download, find Drive.



2.Go to the download center.



 Slide down, find " USB Display Adapters (WIN) ", and click the check mark on the right to download.

Randar Pissas at the imposed (s)	Bate Bearing	
91 Obusta deleter for USB 3.0 Display Adapters	2014-07-22 8	
00 USB 3.0 Dacking Stations (Windows 7/ 8.1/ 18/11)	2024-06-77	
01 USB Display Adapters (Windows 7/ 8.1/10 (11)	2024-05-79	
44 USB 2.0 Docking Stations (macOS 11.s as newer)	2104-02-10	
05. USB 3.0 Display Adapters (macOS 11 or newer)	2024-02-10	
05 282P485 Masagar	2122-13-10 @	
07 aRDP455 Poissaire	1003-19-00 @	
IN _x8DP485-GPD Configure Guide	810-48-96 Q	
99 Multi-Monitory Assistant App	2025-47-22	
19 MultiPacel Warkstations	2005-13-30	
11 USB to Effected (Woldows 17 8.37 18, ASIX solution)	2020-04-07 05	
12 KN-26002 USS 2.8 Magin Switch	202.42.17 0	

4.Check that the Task center driver is downloading.



5.Once the download is complete, unzip the file.



6.Open the folder and double-click the app to download the driver.



7.Loading.



8.Click Next.



9.After agreeing to the terms, it is being installed.



10.When the installation is complete, click Finish and restart your computer.



11.Connect directly to the device. You can see that the link is complete

12. Find Display Settings in Settings.



13.Connect the product and the display through the four HDMI cables, if the screen is black with no picture, please check if your HDMI cable is faulty, or re-plug the HDMI cable and install the four HDMI cables.

After a normal connection, the computer's screen settings will display several displays according to the display you have connected (as shown in the picture: 1-5 will be displayed after five displays have been connected)Any of the screens in 1-5 can be set as the main display.

If you don't know which screen the numbers 1-5 represent, click Identify and the number will be displayed on the connected screen.

6- Settings	- 0	×
•	System > Display	
Find a setting 9.	Select a display to change the settings for it. Drag displays to rearrange them.	
ft Home		
System		
	1 2 3 4 5	
Time & language Carning Accessibility Phicacy & security Windows Update	Material Reference Material Reference on Material Material Reference on Material Reference and las locates locates and an another assessment Material Reference of the Second Sec	
	Execution movement between displays Detect extern displays Detect	
	Connect to a wineless display Connect	
	Brightness & color	

Screens 1-5 can also be dragged and dropped to your liking.

14.You can choose between the main display and one other screen for duplicating.

8	- a System → Display	
End a setting 9	Series a chipture to champe the settings for it. Onep displays to nonrange them.	
ft Home		
System		
Duroth & devices	1 2 3 4 Depinate similary or 1 and 2	٦
 Network & Internet 	Define deleg in 1 and 3	Т
/ Penonelisation	Duplicate delitings on 1 and 4	Т
E Apps	Duplicate dealetes or 1 and 5	Т
Accounts	Apply Canod Sentity [Danet Desttip to this digiting	Т
Time & language Gaming	Multiple digitized Character the presentation match for your digitizes	0
deseminity	🔯 Mada this ny main diajity	
 Privacy & security Minutows Epidete 	Renerster window locations based on wenker connection	
	Minimize windows when a inciditar is disciproveded	
	Eine sunse maxement leinenen dieplags	
	Descroter during Delet	
	Convertis a window display Convert	
	Englishers & other	

15.As shown in the figure: after selecting 1 display and 2 displays for duplicating.

Click Keep changes as soon as you've set it up.

4 Gellinge				- a ×
•	System > Display			
	Select a display to change the settings for it	Drag displays to rearrange t	wit.	
ft Hame				
1 🖬 System				
O Buetooth & devices	3	4	5	112
Network & internet.			,	
/ Personalization				
1 April 1	Keep these displa			
🕹 Accounts	Air Beverting to previous dis	play sattings in 7 seconds.	klavetily Duple	cate depiction on 1 and 2
3 Time & language	an Mun Keep charges	Acres 1		
(B) Carring	Cons Konp (Nanger			
* Accessibility	Upto this my main deploy			
Privacy & wourky	Renerter sindos locations			
Windown Update	-			
	Minimilae windows when a mi	onitie is disconnacted		
	Case cursor movement betwee	en displays		
	Detect other display			Datact
	Connect to a scinuless display			Connect
	Brightness & color			

16.The setup is complete as it is, and you can choose between the home screen and any of the screens to duplicate.

6- Settings	-	0
•	System > Display	
Find a setting Q	Select a display to change the settings for it. Drag displays to rearrange them.	
A Home		
System		а.
0 Bluetooth & devices	3 4 5 112	
 Network & internet 	5 4 5 IIZ	
/ Personalization		
Apps		
Accounts	Identify Extend desitop to this display	
3 Time & language		
60 Gaming	Multiple displays Choese the presentation mode for your displays	^
* Accessibility	Make this my main display	
Privacy & security		
😏 Windows Update	Remember window locations based on monitor connection	
	Minimize windows when a monitor is disconnected	
	Ease cursor movement between displays	
	Detect other display Detect	
	Connect to a wineless display Connect	
	Brightness & color	

The situation of MAC OS

The link address of the chipset manufacturer is shown below: https://www.mct.com.tw/download.php?lang=en&tb=1&cid=32&ot=all

1.Please go to MCT official website, click the upper right corner to download, find Drive.



2.Go to the download center.



3.Slide down, find " USB Display Adapters (MAC) ", and click the check mark on the right to download.

Cana Scheruge Sap	Autor Paul Press Instantia	Inter Descript
	81 Obanta driver for USB 2.0 Display Adapters	2014-07-03 (E)
	10 018 1.0 Decking Statuess (Windows 7/ 8.1/10/11)	2024-00-70 (i)
	81 USB Display Adapters (Windows 7/ 8 1/10 /11)	3824.05.79
	H USB 2.0 Decking Stations (macR5 11.x or newer)	3844-84 (c)
	45 USE3.0 Display Adapters (macDS 11 or news)	2024-02-10
	94 2RDPASS Manager	303-344 @
	87 JRDP455 Ticroware	1623-00-68 @
	H 280P405-DP0 Configure Code	2027-204-06 ©
	19 Multi-Monitors Assistant App	1813-41-12 ©
	19 MultiPoint Workstations	2010-20-20
	11 US& to Ethernet (Windows 7/ 8.1/ 10, ASIE salution)	2021-04-07 05
	12 KM-C6802 US8 2.0 Magie Switch	200.43.W Q

4.Check that the Task center driver is downloading.



5. Once the download is complete, unzip the file.



6.Open the installer in the folder and click Install.



7. When the installation is complete, click and restart.



8. When the reboot is complete, open the screen link Settings in the upper right corner of the screen.





10.Go to Settings to find Security & Privacy and slide down to find the check box for Consent.



9. Tap to open the screen recording Settings .

11.Tap to open screen Settings.



12. Turn on the screen recording Settings to enable USB Displays.



13. Then open the extract folder in the Apple terminal program rewrite.



14.Clicking in will bring up this screen.

 Command - sudo: uninstall-usb-display-driver.command - sudo: uninstall-usb-disp... Last login: Tue Aug 15 14:28:22 on console mc@nets-HeckBock-Pro = X / volumes/MCT_Tigger_Device_Driver-4.e-2823-88-13/unins tall-usb-display-driver.command ; exit; Most components require root privileges to uninstall. We are about to run those commands using "sudo", please enter your password if asked.
 Pessword:

Fill in your device password

(because Apple privacy does not see the password input, just enter the password, then press Enter) and restart the computer.

15.After the restart is complete, insert the device, and then check the other monitor.

Left click on the Apple icon, select "System Preferences", and click on "Display".

About This Mac		••• C > III System Preferences						Q tuest		
System Preferences		0	Sign in to y	our Apple II					Sign In	
App Store		0	-							
Recent Items	>	Conserval Conservat	Desiring &	Dock &		0	Q	Language	A Lines	
Force Quit Finder	0%07	0	0			0	Ā	54		
Sleep		internet Accounts	Perrych	Water & Apple Pup	Ders & Drives	Accessibility	Screen Time	Coloradore	Decurity & Privally	
Restart Shut Down				Real and	-		Keshaari	101040		
Lock Screen	~ % Q		=	-	0		0			
Log Out SAM	0 # Q	Displays	Portanti & Scanners	Ballary	Date & Time	Staring	Tine Machine	Stamp Disk		

16.Connect the product and the monitor via the four HDMI cables. If the screen is black with no image, please check if your HDMI cable is faulty, or re-insert the HDMI cable and install the four HDMI cables. Find Displays Settings in Settings.



17.If you don't know which screen represents which screen, click on the screen and a red box will be displayed.

The 5 screens can also be dragged and dropped to your liking.



 You can choose between the main display and one other screen for duplica ting.



19.Option to pause mirroring and choose to mirror the main screen with other screens.



1.Mac-based devices do not support rotation modes,

but M1/M2 Macs support conversion modes, while Intel Macs do not.

2.To use this adapter, a device equipped with

USB-C/USB3.0 must support USB3.0 data transmission.

3.The adapter does not support playback of HDCP-protected content on sites like Netflix and Hulu.

Product specification

Product Name	CENMATE-3244TU3
Product Model	USB3.0 C/A to HDMI 4K30Hz x2 +HDMI 1080P60Hz x2 Display Adapter (Support MST)+USB3.0 Type-C(5G)
Product Size	118.5x80.5x12.5mm
Cable Length	about 47 Inch
Input	USB-A/C 3.0 interface
Output	HDMI 4K & HDMI 1080P+USB3.0 Type-C(5G)
Support System	Windows10/8.1/7(32-bit/64-bit)and Mac OSx10 or updated version